



chestnut™

multi-mode highchair

Elevate every mealtime, playtime, and activity from birth to 6 years thanks to chestnut's 9 different modes.

Modes

- 9 modes of use including but not limited to: infant mode in traditional and counter heights, youth chair, and portable booster modes.
- Multi-position recline allows newborn chair to cradle baby comfortably
- Adjustable legs easily bring baby to countertop height
- Booster mode securely attaches to dining chair with included straps
- Removable seat back to customise comfort as your little one heads to toddler stage

Comfort

- 4 position recline from highchair to toddler chair
- SoftTouch 5-point harness keeps them safe and secure
- Sleek design with European beechwood legs

Convenience

- 3 different height positions make it easy to adapt your baby's highchair to match every growth spurt, kitchen counter, and dining table
- 3 position adjustable tray means you'll always have the perfect position for every activity
- One-hand buckle release
- Removable, wipeable seat pads
- Detachable tray insert is dishwasher safe for easy clean up

Usage

- birth to 6 years




mist

mocha

shadow

lola



Model: H2324 **Product weight:** 7.6 kg **Product size:** Highchair mode: | 67.6 x w 57.7 x h 100.6 cm | Worktop height highchair: | 78 x w 65.3 x h 112.8 cm

Usage: birth to 6 years **Testing certification:** EN 14988:2017+A2:2024 and EN 16120:2012+A2:2016 and EN 12790-1:2023